



Supreme Air Products Corp. The next generation of compressed air products do more, and do it better.

# Air Knives

## Installation & Maintenance Guide

Air Knives are the most efficient and energy saving method to deliver compressed air for large drying, cleaning or cooling applications.



Version 1.0



### CONTACT

#### ADDRESS

Supreme Air Products Corp,  
5-2324 Hurontario Street  
Suite 184,  
Mississauga ON,  
L5A 4K4, Canada

#### PHONE & FAX

**US & Canada :** 1-289-236-2001  
**Total Free:** 1-800-470-7202

#### ONLINE

**Sales Email:** [sales@supremeairproducts.com](mailto:sales@supremeairproducts.com)  
**Tech Email:** [support@supremeairproducts.com](mailto:support@supremeairproducts.com)

**Website:** [www.supremeairproducts.com](http://www.supremeairproducts.com)

# 01 Compressed Air Supply & Installation

For lengths of 24" and longer, it's best to connect the compressed air to BOTH ENDS of the Air Knife. If you choose to use the rear ports, be sure to feed each one if there is more than one! If pipe cannot be used, there are mounting holes provided.

MINIMUM PIPE SIZES FOR MANIFOLD LENGTHS				
Total Air Knife Length (Inches)	Manifold Size (Inches)	Length of run (ft) & Size of Pipe (inches)		
		10ft	50ft	100ft
1" to 6"	N/A	1/4" Pipe 3/8" Hose	3/8" Pipe 1/2" Hose	1/2" Pipe 3/4" Hose
7" to 12"	N/A	3/8" Pipe 1/2" Hose	1/2" Pipe 3/4" Hose	3/4" Pipe 1" Hose
13" to 24"	N/A	1/2" Pipe 3/4" Hose	3/4" Pipe 1" Hose	1" Pipe 1 - 1/4" Hose
25" to 36"	N/A	3/4" Pipe 1" Hose	1" Pipe 1 - 1/4" Hose	1 - 1/4" Pipe 1 - 3/8" Hose
36" to 60"	1"	1" Pipe 1 - 1/4" Hose	1 - 1/4" Pipe 1 - 3/8" Hose	1 - 1/4" Pipe 1 - 3/8" Hose
61" to 84"	1"	1" Pipe 1 - 1/4" Hose	1 - 1/4" Pipe 1 - 3/8" Hose	1 - 1/2" Pipe 1 - 3/8" Hose
85" to 102"	1-1/4"	1 - 1/4" Pipe 1 - 3/8" Hose	1 - 1/4" Pipe 1 - 3/8" Hose	1 - 1/2" Pipe 1 - 3/4" Hose
102" to 120"	1-1/4"	1 - 1/4" Pipe 1 - 3/8" Hose	1 - 1/2" Pipe 1 - 3/4" Hose	2" Pipe 2 - 1/4" Hose

# 02 Compressed Air Supply

\*\*All filters should be installed within 10-15ft of the Air Wipe. It's important to use supplied fittings to minimize possibility of air restriction.

**Water removal**

Minimum 10 micron filter, with an automatic (float type) drain.

**Oil removal**

Use an Oil filter installed downstream from the water filter if oil is a concern. Again this should be fitted with an automatic (float type) drain.

## **03** General Operation

### **To increase force**

- Dismantle Air Wipe, install an extra .002" shim and reassemble. This will increase the flow rate, velocity, and force but also increase the compressed air consumption. Assume the doubling of air use and size accordingly.

### **To decrease force**

- A regulator may be added downstream from the oil/water filters to reduce the force required.

## **04** Cleaning

Simply disassemble the unit, and clean all surfaces using a mild solvent and rag. Be careful to not damage the shim (or shims) when reassembling. To prevent contaminants from entering the Air Knife, pass compressed air through the unit.

## **05** Troubleshooting

There are many factors that can cause the reduction in flow or force. Undersized airlines, restrictive fittings, or clogged filter elements are common areas to check. If you suspect below average performance, install a pressure gage at the inlet of the Air Knife, and clean the entire unit.